
ASSEMBLY INSTRUCTIONS



SAFETY WARNINGS AND CAUTIONS

- Review all instructions before assembling the cart.
- Improper assembly can cause personal injury and/or property damage
- Do not overload cart. See specifications for load capacity (Distributed evenly).
- Do not step into or on the cart, or use it as a toy


Specifications	
Load Capacity:	**250kg**
Upper Platform Size:	**450mm x225mm x 805mm**
Upper Platform Height:	**745mm**
Castor Size:	**101.5mm**
Dimensions (LxWxH):	**810mm x450mm x100mm**
Net Weight:	**13.5kg**
Gross Weight:	**15.5kg**

ASSEMBLY

Tools are required: Screwdriver


Turn upper platform upright (#2) and install handle (#1).


1





2


Turn upper platform assembly upside down. Install the columns (two left and two right, #4 and #5) by screwing the 4 bolts into each column onto the upper platform.





















3


Install lower platform (#3) and 4 castors (#6, #7) by screwing the 4 bolts into the column, through the bottom platform and finally into the wheel. Only 1 screw is needed to attach the column to the wheel.














4

Tighten all screws and hex nuts using the wrench (#12) and you are done.

