2026.9.11 (高度90cm)

20S-两轮款-万向新前轮 安装说明书

290 mm

420 mm

Shopping cart



Specifications:
Material：Iron
Product dimensions:17.7x16.9x35.6 in. /(L x W x H)
Basket size: 13x12.6x18.1 in./(L x W x H)
Front wheel size:3 in.
Back wheel size:5.5 in.
Max weight capacity: 60lbs

PARTS



A:2pcs front wheels



B: 1pc back axle part



C: 2pcs back wheels

ASSEMBLY INSTRUCTIONS

1 ATTACH FRONT WHEELS

Press the button and connect the wheel into the front shaft of the cart until it clicks into place. To remove the wheel simply press the button and pull the wheel apart.






A

2 ATTACH AXLE



Remove plastic caps.



Insert the axle on to the back leg of the cart.

B

3 ATTACH BACK WHEELS



Press and hold the secure lock at the center of the wheel.

C

Inset the wheels onto the axle and release the secure lock. Once secure, pull on the wheel to ensure it is locked into place.



Note:
If the wheel comes off when pulled, it has not been attached properly. Please repeat the steps above to attach the wheels.

4 INSTALLATION COMPLETE

