红色线是成品线
梯子说明书24. 11. 3. 9. 19. 11
21x28.5CM

2-3STEP LADDER
User's Manual







Please read this instruction manual thoroughly before starting.

Unfold the ladder fully.

Push down on the top step until the the securing hook locks to the rear bar, so that all steps are horizontal before use.

WARNING

- For domestic use only.
- Always ensure ladder is fully unfolded and hinges, footplates and legs are fully extended before use.
  Ensure the top foot plate securing hook is secured to the rear bar.
- Do not use if damaged in any way.
- **TOTAL Maximum weight load limit: 150KG. Do not exceed the maximum weight load limit.**
- Only one person should mount the ladder at any time.
- Always take care when mounting and dismounting. Always mount and dismount facing towards the ladder.
- Always clear the work area of any hazards or obstacles before use, including overhead.
- Always wear suitable footwear when using the ladder.
- Do not lean from the ladder. Always re-site the ladder to a more suitable position.
- Only use it on a firm, flat and level surface. Never use it on the slippery surface or it may cause serious injury.
- Periodically check that all fixings, especially foot pads, nuts and bolts are secure.
- Children should be kept away from the work area. Do not allow children to climb on the ladder.

DISPOSAL

- Dispose of all packaging, paper, cartons, plastic and plastic bags in accordance with your local recycling regulations.
- At the end of the product's lifespan please dispose of it at an authorised household waste recycling centre.